

PMDX-134

Simple Motherboard

for Gecko G201X and G203V

Stepper Motor Drivers

User's Manual



Document Revision: 1.2
Date: 6 December 2013

PMDX
9704-D Gunston Cove Rd
Lorton, VA 22079-2366 USA

Web: <http://www.pmdx.com>
Phone: +1 (703) 372-2975
FAX: +1 (703) 372-2977

Table of Contents

1.0	Overview	3
1.1	Important Safety Information	3
1.2	Warranty Summary	3
1.3	Trademarks	3
1.4	Features	4
1.5	Updates to this Manual	4
2.0	Quick Setup Guide	4
2.1	Package Contents	4
2.2	Assembly steps	4
2.3	Example Configuration with PMDX-126	5
2.4	Example Configuration Direct to PC Parallel Port	6
2.5	Motor Disable	6
3.0	Connectors	6
3.1	Motor Winding Connectors (J1 through J4)	7
3.2	DC (Motor) Power Supply (J5)	7
3.3	Motor Disable Connector (J6)	8
3.4	Step and Direction Inputs (J10)	9
3.5	Motor Current Connectors (J11 through J14)	9
3.6	Motor Driver Connectors (J21 through J24)	9
4.0	Mechanical Specifications	10
5.0	Electrical and Environmental Specifications	11
	Appendix A – Warranty	12

1.0 Overview

This document describes the configuration and operation of the PMDX-134 Simple Motherboard for Gecko G201X and G203V stepper drivers. The PMDX-134 interfaces between the 26-pin "Step/Dir" expansion connector on breakout boards (or a PC parallel port via a DB-25 to 26-pin ribbon cable) and up to four Geckodrive stepper driver modules, models G201X and G203V. The PMDX-134 **DOES NOT** support the Geckodrive G201, G202, G210 or G212 stepper drivers. Future Geckodrive stepper drivers that accept ground as the step and direction common ("COM") may also be compatible.

Note that Geckodrive, Inc., the maker of the Gecko stepper motor drives, does not manufacture, sell, or nor provide technical support for the PMDX-134.

1.1 Important Safety Information

The PMDX-134 is intended for integration by the purchaser into industrial control systems. It is solely the purchaser's responsibility to assure that the system is configured in a manner consistent with applicable safety requirements. Practical Micro Design, Inc. does not control how this board is integrated into the purchaser's system and cannot be responsible for guaranteeing the safety of your system.

The PMDX-134 is not guaranteed to be fail-safe. The system into which the PMDX-134 is installed should provide fail-safe protection and emergency stop capability.

The PMDX-134 contains circuitry that may be connected to dangerous voltages. Care must be taken that user cannot come in contact with these voltages. An enclosure that allows for modest ventilation, but prevents intrusion by operator's hands and foreign objects, especially conductive byproducts of machining operations, should be utilized with this board. Interlock switches on power circuits should remove power when the enclosure is opened.

Automated machine tools, into which the PMDX-134 may be integrated, can cause injury. Precautions should be taken to assure that operators are trained in their proper operation and safety procedures, and that they are protected from moving parts that may be under remote control and may move unexpectedly.

This product may not be used in life support or other critical safety applications.

1.2 Warranty Summary

The PMDX-134 is warranted against failure due to defective parts or workmanship for 90 days from the date of sale. Refer to Appendix A for complete warranty details.

If you have an item requiring service, please see the support page on the PMDX web site (<http://www.pmdx.com>) for return instructions.

The purchaser must pay shipping to return the unit to PMDX. We will ship the repaired unit back to you via ground transportation at our expense. Repairs are normally completed within 10 business days. See Appendix A for our complete warranty details.

1.3 Trademarks

The following product names used in this manual are the trademark, tradename or registered mark of the respective companies:

<u>Product Names</u>	<u>Company</u>
G201X, G203V, G320X and Geckodrive SmoothStepper	Geckodrive, Inc. (http://www.geckodrive.com)
PMDX-125, PMDX-126, PMDX-133	Warp9 Tech Design, Inc. (http://www.warp9td.com/) PMDX/Practical Micro Design, Inc. (http://www.pmdx.com)

1.4 Features

The PMDX-134 has the following features:

Step and Direction Inputs:

- Ribbon header for 26-pin ribbon cable from breakout board or a DB25 to 26-pin ribbon cable.

Motor Interface:

- 6-pin pluggable screw terminals for four motor winding leads and cable shield.

Gecko Stepper Driver Interface:

- Supports up to 4 each G201X or 4 each G203V stepper drivers
- Wire clamp terminals for the current set resistors

Power Supply Input:

- DC supply input for motor drivers

Special Features:

- "Motor disable" input

1.5 Updates to this Manual

Check the PMDX web site (<http://www.pmdx.com>) for updates to this manual and for related application notes. The latest revision of this manual is available on the PMDX-134 page (follow the links from the main page).

2.0 Quick Setup Guide

2.1 Package Contents

Each PMDX-134 ships with the following items:

- 1 each PMDX-134 circuit board
- 2 each Standoffs, 1-3/16" (use to mount the PMDX-134 and Geckodrive assembly to a heat sink plate)

Note that the PMDX-134 ships without plug-on screw terminal strips for its motor connectors (J1, J2, J3 and J4). You will be re-using the terminal strips from the Gecko stepper driver modules for the PMDX-134 connectors as described below.

2.2 Assembly steps

1. Connect your motor power supply to the motor power connector (J5). **DO NOT PLUG ANY GECKO DRIVES INTO THE PMDX-133 YET.** Turn on your power supply and verify that the "Power On" LED on the PMDX-133 turns on. If so, your power connections are correct. If not, check to see if you have the "+" and "-" wires from your power supply connected to the proper terminals on the PMDX-133.
2. Turn off your power supply.
3. Remove the pluggable terminal strips from each of the Geckodrive stepper driver modules (there should be 2 sections of 6-pins each). **Note that one of the two 6-pin connectors will have the tabs cut off from one side. This connector should be installed on the PMDX-134 connector J2 (for Axis #2) in step 6 below.**
4. Mount the Geckodrive modules onto the heat sink plate (hole pattern for the mounting/heat sink plate is shown in section 4.0). **Do not mix G201X and G203V drivers on the same PMDX-134.**
5. Plug the PMDX-134 onto the Geckodrive modules.
6. Install four of the 6-position pluggable terminal strips from step 3 onto the PMDX-134 connectors J1 through J4 (see note in step 3 above).
7. Connect each motor to the 6-pin terminal strips J1 through J4 on the PMDX-134 (see section 3.6)

8. If you need to use the "motor disable" function of the Gecko drive drivers, then connect your disable circuit to connector J6. See section 3.3 for more information
9. For each Gecko stepper driver module, install the motor current set resistor in the corresponding 2-pin terminal strip on the PMDX-134 (J11 through J14). J11 is for axis #1, J12 is for axis #2, J13 is for axis #3 and J14 is for axis #4. If the Gecko drive driver is equipped with DIP switches for setting the motor current you may use them and omit installing the resistor.
10. The resulting assembly should look similar to Figure 1.




Figure 1 – Sample PMDX-134 and Gecko drive Assembly

WARNING – Do not mix G201X and G3203V stepper drivers on the same PMDX-134.

2.3 Example Configuration with PMDX-126

The PMDX-134 connects to a PMDX-126 (or PMDX-125) using a 26-pin female to female ribbon cable (such as PMDX part number PMDX-HDR26Ribbon).




Figure 2 – PMDX-134 connected to a PMDX-126

NOTE: Set PMDX-126 jumper JP4 according to your PMDX-134 and Gecko drive configuration. If you are using G203V stepper drivers and need the "motor disable" function (see section 3.3), then set JP4 to "on" (jumper clip from the center pin to the "on" pin). If you are using G201X stepper drivers set JP4 to "off" (jumper clip between the center pin and the "off" pin).

2.4 Example Configuration Direct to PC Parallel Port

The PMDX-134 can connect directly to a PC parallel port using a 26-pin female to DB25 ribbon cable and a DB25 male-to-male cable. Note that in this configuration, the only signals that may be used from the PC's parallel port are the 8 step and direction signals on pins 2 through 9. The other output and input signals on the parallel port are not accessible unless some sort of splitter cable or intermediate circuit board is used between the PC and the PMDX-134.




Figure 3 – PMDX-134 connected to PC parallel port

2.5 Motor Disable

For a quick setup, leave J6 with nothing connected. After the system is functioning, see section 3.3 for more information on configuring the *Motor Disable* input.

3.0 Connectors

The PMDX-134 contains the following connectors. Refer to the following sections for details on the pin-outs for each connector. For all connectors, pin “1” is the pin closest to the reference designator (i.e. J1 pin 1 is the pin closest to the “J1” text on the circuit board). In addition, all connectors have square pads on pin 1 (look on the bottom of the circuit board).

Connector	Description
J1, J2, J3 & J4	Motor winding connections for axis driver #1, #2, #3 and #4 respectively
J5	DC power supply input for stepper drivers
J6	Motor Disable connector
J10	26-pin ribbon header
J11, J12, J13 & J14	Current set resistor connections for Gecko stepper drivers axis #1, #2, #3 and #4 respectively.
J21, J22, J23 & J24	Connections to Gecko stepper driver axis #1, #2, #3 and #4 respectively (on the bottom of the board)

Table 1 - Summary of PMDX-134 Connectors

3.1 Motor Winding Connectors (J1 through J4)

These connectors provide access to the motor winding signals from the Gecko drive drivers. They also provide a motor power ground signal that can be used to ground the shield around your motor wiring (if you use shielded cables).

Pin Number	Label	Description
1	none	Cable shield (motor power ground)
2	none	No connect
3	none	Motor Phase A
4	none	Motor Phase /A
5	none	Motor Phase B
6	none	Motor Phase /B

Table 2 – Motor Winding Connector Pin-Out (J1 through J4)




Figure 4 – PMDX-134 Motor Winding Connector Pin-Out Diagram

WARNING – If you use shielded cable for your motor wiring, connect the shield on one end of the cable only. If you connect pin 1 to the shield on your motor cable, do not connect the shield on the other end of the cable.

3.2 DC (Motor) Power Supply (J5)

J5 is a two-position wire clamp screw terminal for the DC power supply input. This power input is used solely as the motor power for the Gecko stepper driver modules. An LED (DS1) lights to indicate the presence of DC power.

NOTE – We recommend that the AC mains input to your power supply be fused. We recommend against having switches in the DC connection from your power supply to the PMDX-134.

Pin Number	Label	Description
1	NEG	Negative DC input terminal (normally isolated from the PC's ground)
2	POS	Positive DC input terminal

Table 3 – DC Power Connector Pin-Out (J5)

WARNING: The voltage connected to the motor power input must conform with the Gecko drive stepper driver specifications. Do not exceed 80 volts DC at the motor power input to the PMDX-134 board. Reversing the motor power polarity will result in significant damage. Verify power connections before applying power.

3.3 Motor Disable Connector (J6)

This connector provides wire clamp screw terminal connections for controlling to Geckodrive's "motor disable" function. This provides a way for external circuitry to enable and disable the motor current from the Geckodrive modules. Use this connector if you need to manually reposition your machine without removing power from your system. If you do not have any motor disable circuitry and do not need this function, leave these connector terminals unconnected.

WARNING – There is no indication back to your PC or motion controller that the "motor disable" function has been activated.

WARNING – Do not mix G201X and G3203V stepper drivers on the same PMDX-134. Doing so will cross-connect isolated and non-isolated grounds!

Pin Number	Label	Description
1	G201X	G201X motor disable circuit (see diagram below)
2	COM	Common terminal for disable circuits
3	G203	G203V motor disable circuit (see diagram below)

Table 4 – Motor Disable Connector Pin-Out (J6)




Figure 5 – Motor Disable Sample Connections

G203V Note: The motor disable circuit for G203V drivers requires a +5V DC reference. This reference can be provided to the PMDX-134 on pin 26 of the 26-pin ribbon cable header (J10) if your breakout board supports this (the PMDX-126 supports this by setting jumper JP4 to "on"). Or you can provide your own +5V reference directly to connector J6 pin 3 (ground referenced to your breakout board or PC ground).

3.4 Step and Direction Inputs (J10)

The PMDX-134 provides a 26-pin ribbon cable header for connections to a PMDX-126 breakout board or SmoothStepper. This connector can also be used with a "ribbon cable to 25-pin "D" connector" adapter cable to connect directly to a PC parallel port.

The pin-out on this connector follows the standard for PC parallel port signals on a 26-pin ribbon cable except that only parallel port pins 2 through 9 and the ground signals are connected.

<i>Parallel Port Pin #</i>	<i>PMDX-134 function</i>	<i>Parallel Port Pin #</i>	<i>PMDX-134 function</i>
2	Axis #1 Direction	6	Axis #3 Direction
3	Axis #1 Step	7	Axis #3 Step
4	Axis #2 Direction	8	Axis #4 Direction
5	Axis #2 Step	9	Axis #4 Step
18 to 25	Ground	26	+5V reference for G203V motor disable (see section 3.3)
		(see note 2)	

Table 5 – Signal Assignments from 26-Pin Ribbon Header (J10)

NOTE 1 – The parallel port pin numbers reference the pin numbers of the PC's DB25 parallel port connector.

NOTE 2 – Pin 26 can be used to bring a +5V reference onto the PMDX-134 from your breakout board (such as a PMDX-126). This pin is not available on a PC parallel port (which only has 25 pins).

3.5 Motor Current Connectors (J11 through J14)

These 2-pin screw terminal connectors provide a place to install resistors that determine the GeckoDrive motor current. Note that some GeckoDrive modules have DIP switches that can be used to select the motor current. If the DIP switches are used then do not connect anything to these connectors.

3.6 Motor Driver Connectors (J21 through J24)

These connectors provide for up to four GeckoDrive G201X or G203V Stepper Driver modules. The step and direction signals from the ribbon cable header are hard wired to specific connectors, as shown in Table 5 on page 9.


<i>Driver Number</i>	<i>Motor Driver</i>	<i>Motor Current Set</i>
Axis #1	J21	J11
Axis #2	J22	J12
Axis #3	J23	J13
Axis #4	J24	J14

Table 6 – Motor Driver Connector Groupings

The PMDX-134 provides a ground reference for the GeckoDrive step and direction opto-couplers. This means that the motor driver moves the motor on the rising edge of the step pulse.

NOTE – The PMDX-134 cannot be used with any stepper driver that requires a +5V reference on their step and direction common ("COM") terminal.

4.0 Mechanical Specifications



The datum for all measurements is at (0,0) on the diagram, which corresponds to the corner of the PMDX-134 circuit board.

The height between the bottom of the Gecko drivers and the bottom of the PMDX-134 circuit board is 1.1875" (1-3/16"). This allows mounting the circuit board on standard 1.1875" tall by 0.25" diameter standoffs. The mounting holes in the PMDX-134 are designed to accommodate up to #6 screws.

The maximum component height above the PMDX-134 circuit board is 1.0"

The total height above the mounting (heat sink) plate is 2.25".

NOTE: These mechanical dimensions must be accurately followed so that the connectors on the PMDX-134 will mate properly with the terminal block pins of the Geckodrive stepper motor drivers.

WARNING: *The PMDX-134 should be protected from liquids, dirt, or chips (especially metal chips which can cause shorts) coming in contact with the board.*

Figure 6 - PMDX-134 Dimensions and Mounting Plate Holes

5.0 Electrical and Environmental Specifications

Motor Power: *The voltage connected to the motor power input must be in conformance with the Gecko stepper motor driver specifications. Do not exceed 80 volts DC at the motor power input to the PMDX-134 board.*

WARNING: *Reversing the motor power polarity will result in damage to the PMDX-134 and/or the Geckodrive drivers. . Verify power connections before applying power.*

Step/Direction signals: See the Geckodrive manual for your Geckodrive stepper drivers.

Environmental: Temperature: 0° to +55° C
 Relative Humidity: 20% to 80% relative humidity, non-condensing

Appendix A – Warranty

Statement

Practical Micro Design, Inc. (PMD) warrants that this hardware product is in good working condition, according to its specifications at the time of shipment, for a period of 90 days from the date it was shipped from PMD. Should the product, in PMD's opinion, malfunction within the warranty period, PMD will repair or replace the product without charge. Any replaced parts become the property of PMD. This warranty does not apply to the software component of a product or to a product which has been damaged due to accident, misuse, abuse, improper installation, usage not in accordance with product specifications and instructions, natural or personal disaster or unauthorized alterations, repairs or modifications.

Limitations

All warranties for this product, expressed or implied, are limited to 90 days from the date of purchase and no warranties, expressed or implied, will apply after that period.

All warranties for this product, expressed or implied, shall extend only to the original purchaser.

The liability of Practical Micro Design, Inc. in respect of any defective product will be limited to the repair or replacement of such product. Practical Micro Design, Inc. may use new or equivalent to new replacement parts.

Practical Micro Design, Inc. makes no other representations or warranties as to fitness for purpose, merchantability or otherwise in respect of the product. No other representations, warranties or conditions, shall be implied by statute or otherwise.

In no event shall Practical Micro Design, Inc. be responsible or liable for any damages arising

- (a) from the use of the product;
- (b) from the loss of use of the product;
- (c) from the loss of revenue or profit resulting from the use of the product; or
- (d) as a result of any event, circumstance, action or abuse beyond the control of Practical Micro Design, Inc.

whether such damages be direct, indirect, consequential, special or otherwise and whether such damages are incurred by the person to whom this warranty extends or a third party.